




Coverbasket Parts List



- B** - Axle Housing
 - D** - Elbow
 - E** - Basket Arm
 - F** - Gas Spring
 - G** - Small Hinge
 - H** - Large Hinge
 - I** - Bumper
- Threaded Socket**

Threaded Socket -----

(F) Gas Spring -----

Threaded Socket -----

